


Wasp Inspection Cover

Remove the three screws attaching the Left side inspection Cover.



Replace Lower screw to enable operation of Wasp.

CAUTION

KEEP HANDS CLEAR

Heater block can be at HIGH TEMPERATURES DO NOT TOUCH by hand